

Elegance XL Installation Manual Addendum

Clarification

Page	Subject	Clarification
7	MCP Planning: Power Requirements	An external power outlet must be available to power the MCP. The 2 power outlets provided in the XL Relay Panel containing a standard SuperSTAR will be consumed by the SuperSTAR power supply and the Relay Driver board power supply. If your system contains a relay panel without a SuperSTAR, you will have a power outlet available for the MCP. If not, an electrical outlet must be provided for the MCP.
7,9	6 Conductor 22AWG stranded wire connection between the SuperSTAR and the MCP	All six conductors must be connected to the SuperSTAR. Even though the power for the SuperSTAR is provided by the 12VAC 1600 MA transformer the positive voltage from the MCP STAR chain must be present to provide a reset to the SuperSTAR at power up.